


**THIS TECH BRIEF COVERS SEA65RGB AND SPXWPRGB RGB CONTROL MODULES THAT MAY LOCK INTO DEMO MODE. CAUSE IS DIRECTLY RELATED TO PRESSING LIGHTING COMMANDS IN RAPID ORDER WHICH CAUSES THE MICRO PROCESSOR TO OPERATE IN "SAFE MODE" .**

**To reset the RGB controller -  
Press and hold the 2 lower buttons  
at the same time on the  
remote (color -) & (bright -) for 5 seconds  
and the unit will return to  
standard operating mode.**



### **PART #'S COVERED BY THIS BRIEF**

**SPXWPRGB4  
SPXWPRGB5  
SEA65RGBS  
SEA65RGBW  
SEA65RGBB**

### **TECHNICAL SUPPORT:**

727-592-5991  
Mon-Fri 9AM-8PM EST  
Sat 9AM-7PM EST  
[support@aampglobal.com](mailto:support@aampglobal.com)

Stinger is a Power Brand of AAMP Global  
15500 Lightwave Drive, Suite 202  
Clearwater, Florida 33760